

THINNED CELLULOSE SANDING SEALER



Product Description

Our cellulose sanding sealer is prethinned down to our preferred ratio which penetrates deeply into your wood, producing a smooth surface after a few coats over which you can apply your final finish perfectly.

We've tried lots of different sanding sealers and have discovered this cellulose sealer and thinners mix to be perfect for both standard, coloured and textured work.

This is our preferred sealer for use over the Intrinsic Colour Collection, or other water based wood stains. Note that it is common for a little of the added colour to be removed from the surface when using this product. See the Intrinsic Colour Collection for specific usage advice. Supplied in a 500ml (17.6oz) cone top bottle.

Click for Information and Videos at www.hampshiresheen.com

Basic Application

- 1: Shake well before use.
- **2:** Sand and finish your work as normal, ensuring the surface is dust free;
- **3:** If applying water based colour, do so *before* applying the sealer and allow the colours to dry completely;
- **4:** Evenly apply cellulose sanding sealer with a paper towel or cloth and allow to dry thoroughly;
- **5:** Apply more coats until wood surface is smooth, allowing to dry between coats;
- **6:** Lightly de-nib the dry sanding sealer before applying your final surface finish.

Follow Us

For advice, videos, downloads, live demos and to contact us for tech support, search 'Hampshire Sheen' on Facebook, Instagram and YouTube. You can also tag us using # or @ hampshiresheen to share your work with us.

Always read the product labels.

This guide has been produced for Hampshire Sheen Ltd by Martin Saban-Smith RPT. Copyright © 2021. Registered in England no. 09817729. Garthowen Garden Centre, Alton Lane, Four Marks, Hampshire. GU34 5AJ. United Kingdom. V1.0/0321

PRO FINISHING TIPS

- Sanding sealer is used to close the grain in wood, giving an even surface for finishes to be applied over.
 - Clean the dust off the piece before applying, particularly open grained woods.
 - Apply with paper towel.
 - Apply with the lathe stationary.
- Build the product up in *thin* coats, allowing to dry between coats until the surface is even.
- For best results when 'de-nibbing', use the shavings from the piece being sealed. Use *light* pressure.
- Getting lines when applying or de-nibbing? Too much heat! Sand back, reapply and use less pressure.
- When applying over dyes and stains, it is normal for some colour to be removed from the surface.
- Can also be used to stiffen wood fibres prior to the use of texturing tools.
- Ensure product is dry before applying any finish.
 - Firmly replace the lid after use.
- Store in a cool dry place out of direct light, away from heat sources and protect from freezing.
 - Once opened, use within 6 months.
- Use in a well ventilated area and be aware of the strong smell. This is normal for cellulose sealers.

SAFETY FIRST! Always take appropriate steps to ensure the safety of your workshop environment.